



RADIOACTIVE SOURCE LEAK TEST SAMPLE INFORMATION

Company Name:	Radioactive Materials License #:
Mailing/Billing Address:	Certificate Address: (to be printed on Certificates)
Person to be contacted:	Email:
Phone:	Fax:

For the source being leak tested:

Source Isotope:	Source Activity:
Source Serial No:	Assay Date:
Source Model No:	Source Manufacturer:
Person performing wipe test: (please print clearly)	
Date Leak Test Performed:	Leak Test Interval (If blank, a 6-month interval will be assumed)

Return the sample(s), and this data sheet in an envelope or package marked **“LEAK TEST ENCLOSED”** to:

MJW Technical Services, Inc.
 15 Hazelwood Drive, Suite 112
 Amherst, New York 14228

LTK-03

15 Hazelwood Drive, Suite 112 Amherst, New York 14228 716-631-8291 www.mjwcompanies.com
--



RADIOACTIVE SOURCE LEAK TESTING INSTRUCTIONS

Leak Test Kit Contents:

- Plastic bag containing cotton swab (1 for each source)
- Leak test instructions (on back of source sample information form)
- Radioactive Source Sample Information form (1 for each source)

Leak Test Procedure:

1. Latex gloves should be worn when swabbing radioactive sources.
2. For each source to be tested, fill in the requested information on the leak test sample information form (upper section only). If the top section is already completed verify the information and make corrections where needed.

CAUTION: DO NOT DIRECTLY WIPE THE “ACTIVE SOURCE AREA”

3. Remove the cotton swab from the plastic bag. Swab an area close to the **Active Surface Area** or an area that has come in contact with the **Active Surface Area**.
4. Place the cotton swab back into the plastic baggie and label the baggie to identify the source just swabbed.
5. Send the cotton swabs and completed leak test forms back for analysis to:

MJW Technical Services, Inc.
15 Hazelwood Drive, Suite 112
Amherst, New York 14228

Leak tests will be analyzed and the results of analysis will be returned promptly. If a leak test is found to be above the 0.005 micro-curie limit, MJW Technical Services, Inc. will immediately notify the customer.

LTK-03

15 Hazelwood Drive, Suite 112 Amherst, New York 14228 716-631-8291 www.mjwcompanies.com
--